

# 2021-2023 Yamaha VX / GP LIFESLED - U-Bolt Installation

# Step 1

- With a multi-tool you can make shallow cuts into the ABS (as shown) to cut out a small “window”. Or you can remove the ABS top cap and cut it out this way. Either way will get the job done.



# Step 2

- Install the Large center U-bolt direct to fiberglass in a 12/6 o'clock position. Connect sled with our 4" stainless steel carabiner.



# Step 3

- Use our Aluminum Carabiners and position the loop knot so you barely stretch bungees to connect. Bungees will only activate when sled is stretched side to side.

